

## **BlackBatt VEST LINER Fitting Room**

**HOW?** BlackBatt Liners should be worn snug but not tight.

**WHY?** Correct fitting optimizes heat transfer to your body core.

### **How to Measure Your Chest:**

**MEASURING TAPE** - parallel to the ground both in front and back just snug enough not to slip down.

**MEN** should measure to fullest part of the trunk – normally just under the armpits.

**WOMEN** should take a bust measurement at the point of widest circumference.

**BlackBat Vests** have side adjustment tabs to better accommodate a snug fit.

### **SIZING CHART**

Your Chest In Inches	Your Chest in cms	Order Size
31-32	79-81	<b>XS</b>
33-34	84-86	<b>XS</b>
35-36	89-91	<b>XS</b>
37-38	94-97	<b>SM</b>
39-40	99-102	<b>SM</b>
41-42	104-107	<b>SM</b>
43-44	109-112	<b>M</b>
45-46	114-117	<b>M</b>
47-48	119-123	<b>LG</b>
49-50	125-127	<b>LG</b>
51-52	130-132	<b>XL</b>
53-54	135-137	<b>XL</b>
55-56	140-142	<b>XL</b>

**Tall Size information – call 1-866-999-3575 (9-5 M-F Pacific)**