

BlackJack JACKET LINER Fitting Room

HOW? BlackJack Liners should be worn snug but not tight.

WHY? Correct fitting optimizes heat transfer to your body core.

How to Measure Your Chest:

MEASURING TAPE - parallel to the ground both in front and back just snug enough not to slip down.

MEN should measure to fullest part of the trunk – normally just under the armpits.

WOMEN should take a bust measurement at the point of widest circumference.

How to Measure Your Arm Length:

In a riding position – measure from the neck center, over point of the shoulder, back side of elbow, down the outside of arm to wrist.

BlackJack Jacket Sizes correspond to your chest measurement.

SIZING CHART

Your Chest In Inches	Your Chest in cms	Order Size	Sleeve in Inches	Sleeve in cms
31-32	79-81	32	28-29	71-74
33-34	84-86	34	29-30	74-76
35-36	89-91	36	30-31	76-79
37-38	94-97	38	31-32	79-81
39-40	99-102	40	32-33	81-84
41-42	104-107	42	33-34	84-86
43-44	109-112	44	34-35	86-89
45-46	114-117	46	34-35	86-89
47-48	119-123	48	35-36	89-91
49-50	125-127	50	36-37	91-94
51-52	130-132	52	37-38	94-97
53-54	135-137	54	38-39	97-99
55-56	140-142	56	38-39	97-99
57-58	145-147	58	39-40	99-101
59-60	150-152	60	39-40	99-101

Tall Size information – call 1-866-999-3575 (9-5 M-F Pacific)