

BlackJack VEST LINER Fitting Room

HOW? BlackJack Liners should be worn snug but not tight.

WHY? Correct fitting optimizes heat transfer to your body core.

How to Measure Your Chest:

MEASURING TAPE - parallel to the ground both in front and back just snug enough not to slip down.

MEN should measure to fullest part of the trunk – normally just under the armpits.

WOMEN should take a bust measurement at the point of widest circumference.

BlackJack Vest Sizes correspond to your chest measurement.

SIZING CHART

Your Chest In Inches	Your Chest in cms	Order Size
31-32	79-81	32
33-34	84-86	34
35-36	89-91	36
37-38	94-97	38
39-40	99-102	40
41-42	104-107	42
43-44	109-112	44
45-46	114-117	46
47-48	119-123	48
49-50	125-127	50
51-52	130-132	52
53-54	135-137	54
55-56	140-142	56
57-58	145-147	58
59-60	150-152	60

Tall Size information – call 1-866-999-3575 (9-5 M-F Pacific)